

CCSCALES.COM

800.582.3175



# Tap Test




Rubber Mallet

The numbers on the scale head will become erratic if the weighbar is bad



## If Scale Drifts



Notch place at 12

"A" pin is located at 12 under the notch

"B" pin is located at 2 on the right side

"C" pin is located at 5 on the bottom right

"F" pin is located at 10 on the top left

"D" pin is located at 7 on the bottom left

A-C = 350 Ohms  
B-D = 350 Ohms  
E to All = Open

## Clock Positions



## Color Code For Ohms

### Weigh-Tronix

Red - White = 350 ohms

Green - Black = 350 ohms

Shield - All

### Digi-Star

Green - White = 350 ohms

Red - Black = 350 ohms

Shield - All



SOLD AND SERVICED BY:  
**CENTRAL CITY SCALE INC.**

2403 26th Ave.  
P.O. Box 197  
Central City, NE  
68826



308946-3591  
www.ccscales.com  
ccscale@hamilton.net



SOLD AND SERVICED BY:  
CENTRAL CITY SCALE INC.

3480 25th Ave.  
P.O. Box 187  
Central City, NC  
28026



302946-0681  
www.ccscales.com  
ccscale@verizon.net